

## **INSTRUCTIONS FOR INSTALLING TAILGATE LOWERING LINK STOWING MAGNETS**

Find a location under the bed rail near the tailgate on each side of the bed that you can conveniently reach.

Place a generous dab of RTV silicone on each of the magnets and place in the desired locations.

Let the magnets set for 24 hours before using to secure links.

